


TO REPLACE BATTERIES

1



2



Requires 4 "AA" 1.5V batteries (sold separately) - Battery removal and replacement must be done by adult only.

- Do NOT use rechargeable (nickel-cadmium) batteries • Do NOT recharge NON-rechargeable batteries • Do NOT mix old batteries with new or different types of batteries • Do NOT mix alkaline standard (carbon-zinc) batteries or rechargeable (nickel-cadmium) batteries • Do NOT place batteries near open flame or heat • Remove batteries from product before storing for an extended period of time • Only batteries of the same or equivalent type as recommended are to be used • Batteries are to be inserted with the correct polarity • Exhausted batteries are to be removed from the costume • The supply terminals are not to be short circuited.

DISPOSAL - This product contains batteries and electronics that may be harmful to the environment; they should not be discarded with normal household waste but taken to your local collection center for recycling.

- Please retain this information for future reference.